

# BLUE'LOG XM / XC

## OPTIONAL LICENSES



### DESCRIPTION OF FUNCTIONS

The functionality of blue'Log XM / XC can be extended with a number of optional licenses.

For detailed information regarding each license, visit [www.meteocontrol.com](http://www.meteocontrol.com).

### FEATURES

- + Extension of blue'Log XM / XC functionality
- + Licenses are linked to a specific device. The serial number of the blue'Log applies for identification
- + Licenses have no expiration date
- + Within the scope of a repair (RMA), you can request a transfer of your existing licenses from the defective blue'Log to the replacement device

### OPTIONAL LICENSES

557005 OpenVPN license blue'Log XM / XC

557006 SFTP / FTP-Push license blue'Log XM / XC

557007 IT infrastructure license (LDAP, SCEP, SSL)

557008 Modbus Power Control license blue'Log XC

557009 SCADA Interface license blue'Log XM / XC

557010 Automatic grid disconnection license blue'Log XC

557011 WEB'log Slave mode license blue'Log XM

557012 Modbus configurator license blue'Log XM / XC

557013 External PPC blue'Log license XM / XC

#### Remote Power Control<sup>1)</sup>

557122 Remote Power Control license  $\leq$  200 kW blue'Log XC

557123 Remote Power Control license  $\leq$  1 MW blue'Log XC

557124 Remote Power Control license  $\leq$  3 MW blue'Log XC

557125 Remote Power Control license  $\leq$  5 MW blue'Log XC

557126 Remote Power Control license  $\leq$  10 MW blue'Log XC

557127 Remote Power Control license  $\leq$  20 MW blue'Log XC

557128 Remote Power Control license  $\leq$  50 MW blue'Log XC

557129 Remote Power Control license  $\leq$  100 MW blue'Log XC

557131 Remote Power Control license Utility blue'Log XC

<sup>1)</sup> Maximum AC active power of the plant

---

## LICENSE UPLOAD

- + Order the required license
- + Once ordered, meteocontrol will send the license by email
- + To activate the license, you must upload the license file to the corresponding blue'Log
- + Upload the license in the menu **System > License**
- + If activation is successful, a green check mark appears in the table **Installed licenses**

Licence upload

---



When changing the license from X-Monitoring to X-Control, the data logger is reset to its factory settings.

Select file

Upload licence

---

## PLACING AN ORDER

Contact meteocontrol Order Management to order licenses. When ordering, please provide the 14-digit hardware serial number of your data logger.

Please note that licenses issued for a specific blue'Log XM / XC cannot be used for any other device.

Phone + 49 821 34666-43  
[order@meteocontrol.com](mailto:order@meteocontrol.com)

---

Further information: [www.meteocontrol.com](http://www.meteocontrol.com)